



Introducing a new guide book for distributors – The “**Shooter’s Guide for Etnyre Asphalt Distributors**”.

Written to help distributor owners in planning their shooting jobs.

This book should be used whenever you:

- 1) Want to pre-determine what truck speed the driver should maintain.
- 2) Are shooting light or heavy rates and want to know if you can or cannot shoot them.
- 3) Want to verify that the nozzles on your spraybar are the proper size.
- 4) Want to know what truck speed range must be used to accommodate the nozzles you have on the bar.
- 5) Need to know, for light rates, if you must switch to an “every-other-nozzle” configuration or perhaps a “one-nozzle-per-foot” scheme for a given nozzle size.
- 6) Want to understand the correlation of your truck speed and pump rate for a given application rate and bar width.